

"SO" PREFIX OFFSET EYERING MOUNTING ORIENTATION



Schrader Valve

The offset eyering shock with small gas reservoir, as shown above, is supplied on shock numbers such as G1SO74-5. The purpose is to provide additional clearance between the shock and the upper A-arm ball joint. The Schrader valve is to the inside of the car. This allows for full compression without damaging the shock. It is recommended in several applications.

